



## ***Body Repair Tech Note: Disable Remote Access When The Vehicle Is At The Body Shop***

*Body Repair Tech Notes provide information about Tesla-approved methods and practices for body repair. These instructions assume knowledge of motor vehicle and high voltage electrical component repairs, and should only be executed by trained professionals. Tesla Motors assumes no liability for injury or property damage due to a failure to properly follow these instructions or for repairs attempted by unqualified individuals.*

Tesla vehicles are equipped with remote access that allows customers to perform vehicle functions remotely via a mobile application. Disable remote access when the vehicle is at the body shop to prevent remote activation of features that might cause the vehicle to behave unexpectedly.

On the touchscreen, touch **Controls > Settings > Safety & Security > Remote Access > Off**.

**NOTE:** Turn Remote Access on before returning the vehicle to a customer.

*For feedback on the accuracy of this document, email [collision-techinfo@tesla.com](mailto:collision-techinfo@tesla.com).*